



1. Install fixed panel using your preferred method (brackets, channel, etc.)
2. Install the centre of the mounting blocks from the ST01 Wall Brackets 12mm inside the fixed panel & inline with the centre of the holes on the fixed panel.
3. Cut the rail to length allowing clearance either end for the mounting blocks inside the ST01 Wall Brackets.
4. Slide 2 x ST02 Door Stops onto the rail, one at either end, followed by the ST01 Wall Bracket Sleeves.
5. Install the rail onto the fixed panel & wall using the 2 x ST05 Button Fixings (remove extra nylon washer for 10mm glass) & slide the ST01 Wall Bracket Sleeves over the mounting blocks and tighten grub screws.
6. Install the ST04 Rollers to the door and hang door on the rail.
7. Install the ST04 Guides to the door and adjust in conjunction with the Rollers.
8. Slide the ST02 Door Stops into position and tighten grub screws.
9. Install ST03 Floor Guide onto bottom of fixed panel and under door.



DETAILS

Modern Sliding Shower System - 2000mm Wall to Wall Fixing Set

- Suitable for 8mm & 10mm glass
- 45kg weight capacity
- 3000mm Sliding Rail also available (ST08)

FINISHES

- Polished
- Satin
- Matt Black
- Other finishes available by request

Base Material: 304 Stainless Steel