



- LL = Track length
- FB = Leaf width
- TK = Distance door handle to edge of leaf
- TW = Distance door handle to wall
- Y = Distance to first drill hole
- A = Distance between suspension bolts
- T \ddot{U} = Door clearance
- LH = Clear height
- LB = Clear width
- GH = Total height
- FH = Leaf height
- $\ddot{O}W$ = Opening width
- SH = Panel height

Wall Installation Kit Includes:

- 1 x 2450mm track
- 1 x concealed wall bracket
- 2 x double roller carriages
- 2 x end caps for concealed wall bracket & track
- 2 x tube buffers
- 1 x hold-open spring
- 2 x glass clamping plates with individual covers & black plastic end caps
- 1 x adjustable glass floorguide
- No handle included

DETAILS

Geze Perlan 140

- 140kg weight capacity for 8/10/12mm toughened glass
- Suitable for door widths between 500 & 1240mm and various softstops
- See page 4.2b for recessed clamp glass preparation & clamp details
- Email manufactured@mfgs.com.au for custom length kits and those requiring continous clamp covers, track covers spacers, fixed panel profile, etc.
- For further information please refer to download section at www.mfgs.com.au

FINISHES

- Natural Anodised
- Satin Stainless Anodised

Base material:
Aluminium